
MechaLock - Keyless Bushings

Overview

Features of MechaLock Keyless Bushings

- The MechaLock is a fastening tool to tightly fasten a hub to a shaft by using friction. This is accomplished by converting screw tightening power into pressure on the tapered inner diameter surface of the hub and the tapered O.D. of the shaft.
- A hub (such as pulleys, gears and sprockets) can be easily connected with a shaft by screwing.
- · It is well suitable for applications with repeated forward / backward rotation as it virtually eliminates backlash.
- It can also handle some thrust.
- · Design allows for infinite phase adjustment after installation.
- It saves complex key machining on shafts and hubs as well as polishing in assembling, which leads to total cost reduction.

Structure of MechaLock Keyless Bushings



Installation

- ①Wipe off the shaft surface and apply oil or grease.
- (Do not use any oil or grease containing molybdenum disulfide agent.)
- ②Wipe off and apply oil and grease on contact surfaces of MechaLock and Hub. Apply oil or grease to the thread and seat of lock screws.
- ③Please insert the shaft after assembling the MechaLock and Hubs temporarily. (Do not tighten the screws before inserting the shaft)
- 4)After locating, tighten the locking screws using a torque wrench in the diagonal line order, beginning lightly (approx. 1/4 of the predetermined tightening torque).
- (5) Tighten the screws further to an increased torque (approximately 1/2 of specified
- ⑥Tighten the screws up to the specified torque.
- 7Finally tighten the locking screws in circumferential order.

Removal

- Be sure to work after the system is completely shut down.
- · Loosen the lock screws in circumferential order.
- · Insert a screw in a hole for removal and tighten evenly. · Repeat "Installation" process for re-installation

Cautions

- · Be sure to apply oil or grease to shaft surfaces, contact surfaces b/w MechaLocks and hubs, tightening screws before installation. If not, the MechaLock may not be tightened firmly; the shaft may slip at rotation. However, do not use oil or grease with tapered portion of inner and outer
- · Tapered portion of inner ring and outer ring will get into each other even with a little shock from conveyance. Loosen the screw and nut and disassemble parts to release tapered parts before installation.
- · Please insert the shaft after assembling the MechaLock and Hubs temporarily. (Please do not tighten the screw before inserting the shaft. MechaLock may deform.)
- · Use a torque wrench to tighten the screws.
- · Do not use lock screws other than those included.


Selection Table

Part Number	MLSL	MLR, MLRP MLRS	MLM, MLMB MLMP, MLHS	MLA, MLAP MLAT	MLN, MLNB MLNP	
Page	P.1240	P.1241	P.1243	P.1245, 1246	P.1246	
-	Thin	Compact	Standard	Straight Straight for High Torque	Nut	
Series						
Allowable Torque	Δ	0	0	0	0	
Thin (I.D./O.D. Difference)	©	0	0	0	0	
Lightness	0	0	0	0	0	
Centering Function	X	0	0	×	X	
Installation	Δ	0	0	0	0	
Price	0	0	0	0	0	
Feature	Because the screw is installed directly on the hub, the inner and outer diameter difference is small and thin. Applicable to installation on a small hub. Suitable for the aluminum belt pulley, etc.	Because mounting tap of the screw is built in the flange, the inner and outer diameter difference is small and thin. Applicable to installation on a small hub. Centering function is equipped.	Most widely used locking mechanism. High-performance centering function. Available in wide range of sizes, materials and types of surface treatment.	Has larger maximum allowable torque than Standard Type, and locks the shaft and hub firmly. Compact Straight Type for high torque is also available.	Installation can be completed by tightening one nut and is much easier than the conventional locking screw type.	

[•] Can be used on shafts with keyways with width within JIS standards but allowable torque and thrust ratings will be reduced by 15~20%.

MechaLock - Keyless Bushings

Thin



Part Number		,	ъ.	DO D	_		Locking Screw		Max.	Allowable	Mass	Heit Dei -	
Туре	d	D	D ₁	P.C.D.	Т	В	MxL	Qty.	Tightening Torque (N⋅m)	Allowable Torque (N·m)	Thrust Load (kN)	(g)	Unit Price
	5	8	21.5	15	4	9.5	M3x10	3 _	1.9	4.2	1.69	13	
	6	9	22.5	16						5.6	1.87	15	
	8	11	24.5	18						8.5	2.12	17	
	10	13	29	21	5	11.5	M4x18		3.9	18	3.59	28	
	12	15	31	23						23	3.76	31	
	14	18	36	26		14				37	5.21	52	
	15	19	37	27	6					39	5.10	55	
MLSL	16	20	38	28						42	5.17	57	
IVILOL	17	21	39	29						45	5.23	59	
	19	24	42	32						49	5.12	71	
	20	25	46	36	7	15	M5x20		7.8	97	9.68	103	
	22	26	47	37						110	9.98	101	
	24	28	49	39						121	10.0	106	
	25	30	51	41						124	9.90	119	
	28	32	53	43						141	10.0	118	
	30	35	56	46						149	9.89	135	
kqf=Nx0.1019									kgf=Nx0.101972				




Part Number



Configure Online

How to Determine Hub O.D.

After selecting the MechaLock size, hub size and material, confirm that the selected values meet the conditions H≤hub in the right-hand Hub Minimum O.D. Table



Recommended Tolerance of Shaft and Hub / Roughness of Surface Shaft 0.D. h7(g6) Ra1.6 or less Hub I.D. Ra3.2 or less

Price | Configure Online



Hub Minimum O.D. Table

kgf / mm²=MPax0.101972

				Ngi / IIIII	-WI 0X0.101372	
		H Hub				
	Side	Yield Point St	Hub			
d	Surface Pressure	206	294	392	Machining	
ď	of Hub MPa	FC350 1018 Carbon Steel 1010 Carbon Steel	Cast Iron	FCD Cast Iron600 1055 Carbon Steel		
5	134	21.5	21.5	21.5		
6	132	23	22.5	22.5	8	
8	123	25	24.5	24.5		
10	153	38	29	29	9.5	
12	139	39	31	31	9.0	
14	161	56	38	36		
15	149	52	38	37		
16	143	52	39	38	11	
17	138	52	39	39		
19	118	51	42	42		
20	198		62	49		
22	196	_*	64	51		
24	184		64	52	10	
25	169	101	63	53	12	
28	160	96	64	55		
30	145	89	66	57		
* Not available	•					

1 -1240