# [PRODUCT DATA] **FINISHING OF EJECTOR PINS AND CORE PIN TIPS FINISHING OF CORNERS OF RECTANGULAR EJECTOR PINS**

## [Product data] COMPARISON OF GUARANTEED RANGE OF SHAFT-DIAMETER PRECISION BETWEEN EJECTOR PINS AND CORE PINS DESIGNATION METHOD AND PRECISION OF KEY FLAT CUTTING OF EJECTOR PINS AND CORE PINS

### Finishing of tips and edges



When ejector pins and core pins are processed to determine the total length, fine, processing burring about 0.02~ 0.05mm(reference values)in length occurs at the edge of the tip. When this burring is removed, a slight sag results.

MISUMI does not process the tip in order to prevent sagging.

The allowable sag R depends on a variety of conditions such as the particular mold being used (precision of mold, characteristics of the formed object, shape, resin type). For this reason, the sag R caused by deburring may be an issue. Use an oilstone, sandpaper, cloth, etc to remove the burring according the precision control standards on your design drawing of the mold being used.

On general purpose machinery, it is common to use slight chamfering (C about  $0.1 \sim 0.3$ ), but as the tips of the ejector pin and core pin come in contact with the formed object, chamfering is generally not carried out or kept to a minimum.

### Comparison of Guaranteed Range of Shaft Diameter Precision between Ejector Pins and Core Pins



Designation Method and Precision of Key Flat Cutting of Ejector Pins and Core Pins Method of key flat cutting





When designated according to shaft diameter, in order to designate the shaft diameter  $\times \frac{1}{2}$ Shaft diameter selection type - 0.05mm increments possible Shaft diameter designation (0.01mm increments) type --- 0.005mm increments possible Shaft diameter designation (0.005mm increments) type --- 0.0025mm increments possible Shaft diameter designation (0.001mm increments) type 🛛 — 0.0005mm increments possible







When designated using free dimensions Designation is only in 0.1mm increments

Hints and tips

About processing burring: When cutting (with a blade) or grinding (with a grinding stone) steel, small splinter shaped burrs occur on the edge of the processed surface. For example, just like splinters occur when wood is cut with a saw, similar small splinters occur when processing

metal. These splinters are called burrs. In general, the size of the burrs is smaller for harder materials. On the other hand, the pieces of material that melts and is caught in gaps during casting, die-casting, and molding of plastics are called flash. In English, the burrs caused in processing are called BURRs, while those cause in molding are called FLASH, or

 $\Rightarrow$ 

Deburring

corners

FIN. Reference: Zukai Kikai Yougo Jiten (Illustrated Dictionary of Machinery), THE NIKKAN KOGYO SHIMBUM, LTD.

#### Precision of key flat cutting

①When key flat cutting is designated according to shaft diameter.

Category	Key flat cutting tolerance		
Ejector pins	0 0.1		
Ejector pins alterations VKC•VWC•VAK•VAW	-0.02		
Core pin shaft 0 diameter tolerance -0.003			
Core pin shaft 0 diameter tolerance -0.005	0-0.01		
Core pin shaft -0.01 diameter tolerance -0.02			

2)When	designated	with	free	dimensions	

Shaft  $KC > \frac{diameter}{2}$ 

Category	Key flat cutting tolerance		
Ejector pins	-0.1		
Ejector pins alterations VKC•VWC	_0.02		
Core pin shaft 0 diameter tolerance -0.003			
Core pin shaft 0 diameter tolerance -0.005	0		
Core pin shaft -0.01 diameter tolerance -0.02			

Finishing of corners of rectangular ejector pins



For rectangular ejector pins, P and W dimensions cannot be measured if there is burring, so remove the burring from the corners. As a result, a maximum of 0.03mm of burring R occurs. However, the deburring of edges is not carried out. This deburring is for measuring the P and W dimensions and may leave some burring.

 $4-R \leq 0.03$  (deburring R)